


K1说明书 尺寸:145*210mm

印刷:120g铜版纸 白底黑字







⚠ GENERAL WARNING:Riding an electric scooter is a sport and entertainment tool for children. There may be dangers in the process of riding, such as losing control or falling and wrestling. Therefore, safety precautions should be taken before riding and the risks of this sport should be explained to your child. It has the property of a vehicle, so it also has the safety risk of all vehicles. In China there is no such as electric scooter related national standards and regulations of the country or region, please be sure to strictly abide by the safety requirements of this manual for drivers and for violation suggests the use of this manual to all property, personal loss, accident, legal disputes, and other all adverse events caused by conflicts of interest, will not assume any direct or joint liability.

- 1. This product is an electric scooter for children. It can only be used by one child. Do not carry others at the same time.
- 2. Please wear safety helmet and other protective equipment when riding this product. 3. Do not ride this product in unsafe or illegal places.
- 4. Please practice in the open space first, avoid riding on the traffic line, and drive after skilled operation.
- 5. Do not take dangerous actions or ride with one hand while the vehicle is running.
- Keep your feet on the scooter. 6. Do not try to directly pass through the steps with a gap of more than 3cm, as it
- may overturn the car, causing injury to the driver or damage to the car; Steps lower than 3 cm should also be avoided as far as possible. 7. The maximum speed of the scooter is 15 km / h, for your driving safety, please try
- to avoid using it at night. 8. Do not use this product in an environment below - 5 ° C.
- 9. In case of uneven or poor road conditions, please slow down and drive slowly or get off the vehicle.
- 10. Do not ride this product on the terrain with oil or ice on the surface. 11. When riding, please adjust the height of the product to an appropriate position according to your height to ensure driving safety.
- 12. Do not immerse the product in a water depth of more than 3cm or be directly sprayed by water to avoid the impact of water on the vehicle's electrical.
- 13. In bad weather such as rain, snow and strong wind, please try to avoid riding to

WARNING: ALWAYS INSPECT E-SCOOTER PRIOR TO RIDING. Properly inspecting and maintaining your scooter can reduce the risk of injury. Always inspect your scooter before riding and regularly maintain it. Check and secure all fasteners before every ride. Replace worn or broken parts immediately. The toy shall be used with caution, since skill is required to avoid falls or collisions causing injury to the user or third partes.

Maintenance and repair

Cleaning and storage of electric scooters:

If the surface of the electric scooter body is polluted, use a soft cloth to take a small amount of clean water and wipe it. If there is a stain that is difficult to clean, you can apply it with toothpaste and brush it repeatedly with a toothbrush. Then clean it with a damp cloth. If the plastic parts of the car body are scratched, they can be polished with sandpaper or other abrasive materials. Tip: Do not use alcohol, gasoline, kerosene or other corrosive and volatile chemical solvents for trench cleaning, otherwise the appearance and internal structure of the car body will be seriously damaged. It is forbidden to use the pressure water gun to spray and wash. Make sure that the electric scooter is turned off, and that the charging cable has been unplugged and the rubber cover of the charging port has been fastened tightly. Otherwise, it may get an electric shock or cause serious failure due to internal water inflow. When not in use, store the electric scooter indoors in a dry and cool place as much as possible, and try to avoid storing it outdoors for a long time. The outdoor environment of sun exposure/overheating/supercooling will accelerate the aging of the appearance and tires of electric scooters and reduce the service life of electric scooters and their battery packs.

Maintenance of electric scooter battery


- 1. Do not use battery packs of other models or brands, otherwise there may be safety risks. 2. Do not touch the battery contacts, and do not disassemble or puncture the shell. Avoid short circuit caused by metal objects touching battery contacts. Otherwise, battery damage or casualties may be
- 3. Only the original charger can be used for charging, otherwise there is danger of damage or fire. 4. Improper disposal of used batteries may seriously pollute the environment. Please comply with local regulations when discarding this battery pack. Please don't Discard this battery pack at will to jointly
- 5. Please fully charge the battery and then store it after each use, which is beneficial to prolong the


Do not place the battery in a high temperature higher than 50°C or a low temperature lower than -20°C (for example, do not put the electric scooter or its battery pack in a car in the summer sun). Do not put the battery pack into the fire, or it may cause the battery to fail, overheat or even risk fire. When not in use for more than 30 days, please fully charge it first, store it in a cool and dry place and fully charge it every 60 days, otherwise it may damage the battery, which is not covered by the warranty.


Avoid recharging when the battery is completely exhausted, and try to use it as soon as possible, which can greatly prolong the service life of the battery. In addition, when used at room temperature, the battery pack can play a higher cruising range and performance; however, if used in an environment below 0°C, the battery life and performance will decrease. Typically, in a 20C environment, the cruising range may be only half or lower than that at normal temperature. When the temperature rises, the battery life will


Tip: A fully charged electric scooter will exhaust its stored power after about 120-180 days of standby. There is a smart chip inside the battery to record the charging and discharging situation of the battery. If the battery is not charged for a long time, it will not be recharged. At this time, if it is not charged in time, the battery will probably be over-discharged and damaged. This kind of damage cannot be recovered, and you cannot enjoy the free warranty. (Note: Non-professionals are forbidden to disassemble the battery pack at will, otherwise serious safety accidents may be caused by electric shock or short circuit!











Note: Data and references vary with different models. If there is any change, no notice will be given.

